


FES15M Rim Mounted Monitored Electric Strike Installation Instructions

FES15M Monitored, surface mount electric strike for rim latch control

Door Latch Position



As shown in Figure 1, there should be a 1mm gap between the door latch and the front face of strike keeper to prevent the door from exerting pressure on the keeper when door is closed.


Mounting steps for FES15/FES15M

- 1. Position the strikes against the frame, mark and drill the hole sizes as shown on Figure 2 and 3.
- 2. Drill cable exit hole on door frame.
- 3. Make sure electrical connections are followed correctly.
- 4. When the door is closed, ensure that there is no pressure on the front face of strike keeper.

Power input 12VDC or 24VDC wirings

Power Input	12 VDC – current 200 mA Note: Select from pre-wired assembly to use plugs. There is no polarity on power input.			
Wire output	12 Volt plug:	24 Volt pl	24 Volt plug:	
	RED —	RED		
	BLUE 12 VI	OC/ 200 mA		
	YELLOW —	YELLOW		
	BLACK —	BLACK	•	
DSS (Door Status Sensor)	Black (Common)	Blue (Normally Open)	Orange (Normally Close)	
DSS contact rating	Max. current 2A Max. voltage 30VDC	Note: DSS available on FES15M only		


Install on Timber Door Frame





FES15M Rim Mounted Monitored Electric Strike Installation Instructions

Conversion: Power to Lock <=> Power to Open







Figure 4B



POWER TO LOCK Figure 4B

WARNING:

Do not attempt to swivel the keeper while changing the function. The spring screw must be in place before operating the strike.

Procedure to convert Power to Open (Figure 4A) to Power to Lock (Figure 4B):

- Step 1: Remove the security plug cover (2) with the provided security screw (1).
- Step 2: Remove the spring screw (3) from the opening hole.
- Step 3: Remove the Barbell (4) and replace in reverse position with long part in and short part out.
- Step 4: Replace the spring screw (3).
- Step 5: Refit the security plug cover (2).

Procedure to convert Power to Lock (Figure 4B) to Power to Open (Figure 4A):

- Step 1: Remove the security plug cover (2) with the provided security screw (1).
- Step 2: Remove the spring screw (3) from the opening hole.
- Step 3: Remove the Barbell (4) and replace in reverse position with short part in and long part out.
- Step 4: Replace the spring screw (3).
- Step 5: Refit the security plug cover (2).



0000